

Set Up



1 Attach the bracket to a pillar (e.g. using an Ex-Clamp or cable ties).



2 Pull apart the rods to open the Ex-Disc. There will be some tension so keep pulling until it pops open.



3 Adjust tension to evenly stretch the skin by using an allen key as shown. Repeat on both sides.



4 Pull up on the rod until you hear a click. Repeat on the opposite side.



5 Insert the Ex-Disc into the clamp and close the catch to secure.

EXDISC



EX-DISC
 ▲ 1.0 m (3' 3")
 ➤ 1.0 m (3' 3")
 📦 2.8 kg (6.2 lb)


Take Down



1 Remove the Ex-Disc from the clamp on the pillar. Squeeze the lever to release the catch on the rods. Repeat on the opposite side.



2 Pull the shorter side of the banner in towards the frame. The rods will twist and come together.



3 Place Ex-Disc into bag.

The Ex-Disc is the best way to give your brand 360 impact and combines the practicality of the Boulevard Banner with the movement of the Flying Banner.

This clever design allows the disc to feather out of the wind and the double-sided print shows off your brand from any direction. The image is also easily interchangeable.

The innovative clasps are adaptable, attaching to any size pole - from 50 to 300mm.



www.doubleimpact.com.au

P. (02) 9999 1322 F. (02) 9999 1955